

PKO FIRMLOK® BASIC INSTALL GUIDE

Panel overhang past beam should not exceed 250mm

Longitude overhang from 0 to 1500mm

(For more information please refer to SOLARIS engineering guide)

Put joins under cover - Positioning the beam join on the inside of the structure to eliminate the chance of water entry into the beam as shown below.

